



Verizon M1424WR Antenna Replacement

This guide will illustrate how to remove the Verizon M1424WR antenna without opening the device.

Written By: James Carby



INTRODUCTION


Replace the antenna to address internet connection problems. This replacement is fast, simple, and requires no tools.

Step 1 — Antenna



- Orient the router to where the back side with the ports faces you.

Step 2



- Lower the antenna so that it is parallel to the table surface.

Step 3



- Unscrew the antenna counterclockwise at the threaded base until it is detached.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-20 01:24:35 PM.